

## **AirFom Seat Instructions for Cooper**

1. The AirFom seat is made up of two parts, the black anodized frame and the yellow bottom and back cushion.
2. Remove the old seat, if replacing the standard seat. Otherwise continue to step 3.
3. The AirFom seat frame is made up of two parts, which are joined together. The shorter portion of the frame is the back. The longer portion is the bottom.
4. Position the seat within the cockpit and engage the black half-moon clips with the bottom keel tube and press down into place. If the bottom keel tube has Velcro on it, the clips will snap into place over the Velcro. The ends of the crossbar mounted underneath and to the front of the bottom frame will come to rest on top of the lower longerons.
5. If you are replacing a standard seat with the AirFom seat, mount the short buckle strap with the brass eyelet in the same position as the 2" black webbing that was used with the standard seat. If you are placing an AirFom seat in a new Cooper, clip the seat's webbing straps to the black deck eyes mounted on crossframe #3.
6. Engage the other half of the buckle that is attached to the strap sewn to the frame back. The incline of the seat back can be adjusted by varying the length of this strap.
7. Mount the yellow seat cushion back by slipping the webbing strap sewn to the cushion over the seat back frame.
8. Secure the bottom of the cushion by attaching the Velcro flaps sewn to the sides of the bottom cushion to the Velcro sewn to the bottom of the seat bottom frame.
9. Adding air through the inflation hose or letting some air out can adjust the firmness of the foam seat bottom. We recommend that you start with the valve open (twist counter-clockwise) and add air as desired.
10. The lumbar pillow can be inflated by adding air to it in the same way.